

# Supported Languages for Pepper Robot

Version 06/2018

Supporting ALTextToSpeech,  
ALSpeechRecognition

Locate	Language Name	Dialog code	Tools	Content and Samples	Notifications	ASR Engine	TTS Engine	Activity Launcher	Conversation	Remote ASR Engine
			Choreographe	NAOqi API	Basic Channel	Remote				
	<b>Codification</b>									
ja_JP	Japanese	jpj	⊙	⊙	⊙	⊙	AiTalk	⊙	⊙	⊙
en_US	Englisch	enu	⊙	⊙	⊙	⊙	Nuance	⊙	⊙	⊙
fr_FR	French	frf	⊙	⊙	⊙	⊙	Nuance	⊙	⊙	×
it_IT	Italian	iti	⊙	⊙	⊙	⊙	Nuance	⊙	×	×
de_DE	German	ded	⊙	⊙	⊙	⊙	Nuance	⊙	×	×
es_ES	Spanish	spe	⊙	⊙	⊙	⊙	Nuance	⊙	×	×
zh_CN	Chinese	mnc	⊙	⊙	⊙	⊙	Nuance	⊙	×	⊙
zh_TW	Mandarin Taiwan	mnt	⊙	⊙	×	⊙	Nuance	⊙	×	⊙
nL_NL	Dutch	dun	⊙	⊙	○	⊙	Nuance	○	×	×
ar_SA	Arabic	arw	⊙	⊙	○	⊙	Nuance	○	×	×
ko_KR	Korean	kok	⊙	⊙	○	×	×	○	×	×
pL_PL	Polish	plp	⊙	⊙	○	×	×	○	×	×
pt_BR	Brazilian	ptb	⊙	⊙	○	×	×	○	×	×
pt_PT	Portuguese	ptp	⊙	⊙	○	×	×	○	×	×
cs_CZ	Czech	czc	⊙	⊙	○	×	×	○	×	×
da_DK	Danish	dad	⊙	⊙	○	×	×	○	×	×
fi_FI	Finnish	fif	⊙	⊙	○	×	×	○	×	×
sv_SE	Swedish	sws	⊙	⊙	○	×	×	○	×	×
ru_RU	Russian	rur	⊙	⊙	○	×	×	○	×	×
tr_TR	Turkish	trt	⊙	⊙	○	×	×	×	×	×
nn_NO	Norwegian	nor	⊙	×	○	×	×	×	×	×
eL_GR	Greek	grg	⊙	×	○	×	×	×	×	×

⊙	OK
○	Partial/ Not
×	Not Supported Yet